



## GOLD RX 04-07 eff.var. 1 och 2/cap. var. 1 and 2, 08 eff.var./cap.var. 1 utan/without COOL DX Top




1) Inställning DIP-switch. Switch nr. 1-5. 1 = On, 0 = Off./  
Settings DIP switch. Switch no. 1-5. 1 = On, 0 = Off.

GOLD RX 04-07 eff.var. 1 och 2/cap. var. 1 and 2, 08 eff.var./cap.var. 1 med/with COOL DX Top




**A: GOLD RX/PX/CX/SD04-07, 08/11 eff.var./cap.var. 1**




## C: GOLD RX 04-80 standard, 04-70 sorption

|                                 | DIP1 | DIP2 | DIP3 | DIP4 |
|---------------------------------|------|------|------|------|
| <b>Rotor, standard/sorption</b> |      |      |      |      |
| <b>GOLD</b>                     |      |      |      |      |
| RX 004-008                      | OFF  | OFF  | OFF  | OFF  |



**J: GOLD RX/PX/CX/SD 04-50**



**K: GOLD RX/PX/CX/SD 04-50**

