

1. General

An activated relay is indicated with a LED.


In cases when the alarm is to be forwarded, via a free changeover relay contact, use auxiliary relay TBLZ-1-85.



Remove the motor control cover in the MIRUVENT power roof ventilator. Fit the relay using the mounting pad in an appropriate position in the empty area next to the terminal block.

Dimensions (LxWxH)	37x16x13 mm
Weight	20 g
Enclosure class	IP 20
Operating temperature	-40 - +70°C
Supply voltage	9-30 VDC
Connector data	30 V DC/AC, 1A

5. Electrical connections



The relay is drawn in the deenergized state. In the event of an alarm, the relay switches and makes between C and NO.

